

# England's Stove Works, Inc.

*Pellet Stoves  
Corn Stoves  
Gas Stoves  
Wood Stoves*

P.O. Box 206 Monroe, VA 24574 [www.englishstoves.com](http://www.englishstoves.com) Phone: (800) 516-3636 Fax: (434) 929-4810


## Combustion Blower Gasket

**WARNING: BE SURE TO READ YOUR OWNER'S MANUAL BEFORE INSTALLING OR OPERATING YOUR STOVE.  
ALWAYS FOLLOW ALL CODES.**

If you remove (i.e. for cleaning) or replace the entire Combustion Blower, a new blower flange gasket (Part # **PU-CBG**) should be added between the blower flange and the steel exhaust tube.

To remove the Combustion (exhaust) Blower (Part # **PU-076002B**), the power leads and the pellet vent pipe must be disconnected. Next, remove the screws that hold the blower to the steel exhaust tube and slide the blower from the stove (Ill. 1).

If cleaning your blower, the blower impeller, blower tube and steel blower exhaust tube on the unit should be brushed and vacuumed. However, if you remove **or** replace the entire Combustion Blower, a new blower flange gasket (Part # **PU-CBG**, Ill. 1) must be added between the blower flange and the steel exhaust tube. Scrape any residue or gasket material from the blower and/or stove before installing the new gasket to the blower and re-installing the blower to the stove.



Ill. 1

**Technical Support:** (800) 245-6489  
**Web Site:** [www.englishstoves.com](http://www.englishstoves.com)

