

England's Stove Works, Inc.

P.O. Box 206

Monroe, VA 24574

Phone: (800) 245-6489

Fax: (434) 929-4810

REPLACING THE HIGH-TEMP HOSE


Hi-Temp Hose Insert Replacement:

Replacement of the Vacuum Hose simply involves removing the defective hose and routing the new hose in its place. Be sure to use the hose clamps to secure each end of the hose.

IMPORTANT: When replacing the Hi-Temp Vacuum Hose, be sure to connect the **black** end of the hose to the Exhaust Blower (shown).

PLEASE NOTE: Some stove models are arranged as pictured and some are slightly different; all models require the black end of the hose to be connected to the Exhaust Blower.

WARNING: ELECTRICAL SHOCK CAN OCCUR IF UNIT IS NOT UNPLUGGED.



Connect black end of hose to Exhaust Blower
(Your unit may vary slightly in appearance)

WARNING: STOVE MUST BE OUT (NO FIRE), COOLED DOWN, AND UNPLUGGED BEFORE ANY MAINTENANCE. ALWAYS FOLLOW ALL CODES.

Technical Support: (800) 245-6489
Web Site: www.englishstoves.com

England's Stove Works, Inc.

P.O. Box 206

Monroe, VA 24574

Phone: (800) 245-6489

Fax: (434) 929-4810

REPLACING THE HIGH-TEMP HOSE


Hi-Temp Hose Insert Replacement:

Replacement of the Vacuum Hose simply involves removing the defective hose and routing the new hose in its place. Be sure to use the hose clamps to secure each end of the hose.

IMPORTANT: When replacing the Hi-Temp Vacuum Hose, be sure to connect the **black** end of the hose to the Exhaust Blower (shown).

PLEASE NOTE: Some stove models are arranged as pictured and some are slightly different; all models require the black end of the hose to be connected to the Exhaust Blower.

WARNING: ELECTRICAL SHOCK CAN OCCUR IF UNIT IS NOT UNPLUGGED.



Connect black end of hose to Exhaust Blower
(Your unit may vary slightly in appearance)

WARNING: STOVE MUST BE OUT (NO FIRE), COOLED DOWN, AND UNPLUGGED BEFORE ANY MAINTENANCE. ALWAYS FOLLOW ALL CODES.

Technical Support: (800) 245-6489
Web Site: www.englishstoves.com